

CAT6 connection board

Custom hardware

8-7-2022

Heliostaat.nl

Mark Ursum



End sensor-
NPN input
5V

End sensor-
NPN input
5V

Motor-
Motor+

Encoder-
A
B
5V

Same for other axis